


Výkres náhradních dílu Muck-Truck od r.v.2004



SPARE PARTS LIST

- DP01 Forward / reverse lever
- DP02 Forward/Reverse Lever Grip
- DP03 Handle Bar Grip
- DP87 Throttle lever c/w cable
- DP05 Engine cowling inc handles
- DP07 Forward/reverse tie rod
- DP08 Forward/reverse tie rod & Brake Ball joint
- DP10 Skip Catch/clutch lever
- DP11 Skip Catch/clutch cable
- DP13 Power Drive Bracket
- DP14 Honda engine
- DP15 Engine pulley
- DP16 Clutch pulley
- DP17 Clutch pulley bracket
- DP18 Clutch pulley & skip catch spring
- DP19 Drive belt
- DP20 Drive pulley
- DP21 Transaxle
- DP23 Wheel hub
- DP24 Front Wheel complete
- DP26 Left Torque Stay
- DP27 Right Torque Stay
- DP28 Skip Catch
- DP30 Rear wheel

DP31 Lynch Pin
DP32 25mm Star lock
DP33 Main Frame
DP34 6 cu ft skip
DP35 Decal Set
DP37 Rear axle assembly
DP45 4" wheel
DP53 Brass cable connector
DP54 Gear change grommet
DP55 Cable grommet
DP80 Front wheel Plastic Cap
DP81 Caster wheel Plate
DP82 Caster turn table
DP83 19mm Star lock

Prodej - Servis - Půjčovna